

**注意**

安全に末永くご使用いただくため、以下の指示を必ずお守りください。

**アレルギー体質の方は、ご使用前に医師にご相談ください。**

本製品は「ローズウッド」を使用しております。ローズウッド部にはコーティング加工を施しておりますが、ローズウッド部を手や口で触れると、体質によりアレルギー症状が出る場合がございます。その場合、ただちに使用を中止し、医師にご相談ください。

演奏の前に

手をあらい、口をきれいにすすぎましょう。

リードは折れることがあります

弊社リードは一般的なハーモニカとして十分な耐久性を備えておりますが永久的に使用できるものではありません。リードは振動による疲労によって音程が狂ったり折れることがあります。使用・保存状態によってこの耐久時間もまちまちです。リードが折れる場合、前兆として音程が大きく下がります。この場合直ちに演奏を中止してください。そのまま使用を続けると折れたリードを口に吸い込む恐れがあります。

異物を入れないで

吹口やすき間に異物を入れないでください。故障・破損の原因になります。

シンナーやベンジンでふかないで

シンナーやベンジンなどでハーモニカをふかないでください。変形・破損の原因になります。

ハーモニカを振り回さないで

ハーモニカを振り回さないでください。顔などに当たるとケガをする恐れがあります。

製品に衝撃を与えないで

カバーを強く押したり、かんだり、落とすなど、製品に衝撃を与えないでください。木の特性上、衝撃を与えると割れやすいため、扱いにはご注意ください。

熱くなる場所はさけて

車の中やストーブのすぐ近く、日ざしの強いところにおかないでください。変形・破損の原因になります。

演奏のあとは

たまった水を抜きましょう。製品には変形しにくい材料を使用しておりますが、木の特性上、唾液等、水分によって多少変形することがあります。

**株式会社 鈴木楽器製作所**

〒430-0852 浜松市中区領家2-25-12 TEL (053) 461-2325 (代)

<http://www.suzuki-music.co.jp/>

0109-1A-TYP-MM-113-B



CAUTION



If you are prone to allergies, please consult with a doctor prior to playing this instrument.

This product is made of rosewood and all rosewood parts have been specially coated. However, in the unlikely event of any kind of allergic reaction, please stop using the harmonica immediately and consult a doctor.

Before playing

Clean your hands and mouth.

About the reed fatigue

Our harmonica reeds are amongst the strongest and most durable in the industry today. Suzuki offers one of the longest harmonica warranties in the world because of our superior reed plate technology. However, reeds can not be used permanently. With any vibrating piece of metal, fatigue can become a factor. The life of the reeds depends on how often you use your instrument and your playing style. When your harmonica is tuned down drastically, it is a sign of metal fatigue. Reeds can become out of tune or break. It is recommendable to replace reeds.

Suzuki is not responsible for any damage that occurs due to reed fatigue.

Don't insert any foreign objects into the harmonica via holes.

This could cause damage.

Don't wipe your harmonica with thinner or benzine.

This could cause damage to the outer cover.

Don't jolt your harmonica.

Be careful not to drop your harmonica or put excess pressure on the cover plates. More care is needed on natural wood products, which can be more easily damaged.

Keep your harmonica away from heat.

Don't leave your harmonica near a source of heat such as an oven, or under intense sunlight. This could cause damage to the harmonica.

After each performance

Please drain excess moisture from your harmonica each time you play or after each performance. Wood can be more easily deformed by saliva or moisture, so extra care is needed.



SUZUKI MUSICAL INST. MFG. CO., LTD.
2-25-12 Ryoke Naka-ku Hamamatsu Japan
<http://www.suzuki-music.co.jp/>