

グロッケン SG-3200 取扱説明書

この度は、弊社製品をお買上げいただきまして誠にありがとうございます。本製品を末永く安全にご使用いただくため、この取扱説明書をよくお読みください。お読みになった取扱説明書は無くさないよう大切に保管してください。

⚠ 使用上の注意

- 先のとがったもので叩かないでください**
本製品を先のとがったもので叩くと破損するおそれがありますので、絶対にしないでください。
- 改造・分解はしないでください**
本製品を改造・分解すると製品が破損するおそれがあります。
- 本製品に強い力を加えないでください**
音板の中央部は調律されて薄くなっています。上に乗ったり、倒したり、必要以上の力を加えたりすると製品が破損するだけでなくケガのおそれがあります。
- 付属のマレットは演奏以外の目的に使用しないでください**
マレットを振り回したり、投げたり、人や物を叩くことは、絶対にしないでください。
- 直射日光の当たらない風通しの良い場所で使用・保管してください**
熱くなる場所や湿度の高い場所、また急激な温度・湿度の変化する場所で使用・保管しないでください。製品を傷める原因となります。
- 引きずったり倒したりしないでください**
製品を傷めたり、床を傷つけたりするおそれがあります。また思わぬ事故の原因となります。
- 本製品を演奏目的以外に使用しないでください**
本製品の上に立ち上がる、踏み台にするなど演奏目的以外に使用すると製品を傷めるだけでなく、思わぬ事故の原因となります。
- 平らで十分な広さがある場所に保管してください**
不安定な場所での保管は、転倒や落下などによる製品の破損や思わぬ事故の原因となります。
- 机やスタンドに載せて演奏する際は平らで安定した場所に設置してください(推奨スタンド:DKP-200)**
不安定な場所での使用は転倒や落下などによる製品の破損や思わぬ事故の原因となります。スタンド使用時にはスタンドの取扱説明書の指示に従って正しくお使いください。
- お手入れはやわらかい布で乾拭きしてください**
アルコール・シンナー・ベンジンなどの薬品や溶剤は製品を傷めますので、絶対に使用しないでください。
- 本製品の音板は取り外しできません**
音板を取り外そうとしたり、音板を持って運搬したりしないでください。製品の破損や思わぬ事故の原因となります。

音程の変化について

本製品に限らず、一般的にグロッケンを含む鉄琴は、温度や湿度の変化によって音程が変化します。温度または湿度が高くなるとピッチが下がり、低くなると上がります。これは楽器の特性上起きる現象で、故障ではありません。

フタについて

演奏の際はケースのフタを外してください。演奏後はフタを閉めて収納してください。フタは簡単に取り外しができる構造になっておりますので、収納時はフタが嵌合部にしっかりとハマっているか確認してください。

SG-3200仕様

音域：クロマチック32音 $f^2 \sim c^5$ (F57~C88)
材質：音板/スチール(音板固定式) 本体/ブナ
寸法：73×36×5.5cm
重量：9.5kg
付属品：ケース・マレット2組

推奨スタンド「DKP-200」仕様












寸法：高さ49.5/59/67/75/79.5cm 最大幅73cm 奥行50.5cm
重量：2.5kg



Glockenspiel SG-3200 Owner's manual

Thank you for purchasing SUZUKI Glockenspiel. To ensure you use the instruments safely for a long time, please read this manual carefully. Be sure to keep this manual in a safe place for reference, as needed.

Precautions for use

-  **Do not hit with a hard object.**
Never hit this product with a hard or sharp object as it may cause damage.
-  **Do not modify or disassemble.**
It may damage the product.
-  **Do not apply strong force to this product.**
The central part of the tone bar is tuned and not as thick. It may cause product damage if applying too much pressure or force.
-  **Do not use the attached mallet for any purpose other than playing.**
Never swing, throw, or hit people or objects with the mallet.
-  **Use and store in a well ventilated place out of direct sunlight.**
Do not use or store in a hot place, a place with high humidity, or a place where the temperature and humidity change suddenly. It may damage this product.
-  **Do not drag or knock over this product.**
It may damage this product or damage the floor. It may also cause an unexpected accident.
-  **Do not use this product for any purpose other than the musical performance.**
Standing or climbing on this product may damage the instrument and cause an accident.
-  **Store on a flat surface with enough space.**
Storing this product in an unsuitable place may cause damage.
-  **When playing on a desk or stand, place this product on a flat and stable place (Suggested stand: DKP-200).**
Using this product in an unstable place may cause damage to this product or an unexpected accident due to turnover or falling. When using the stand, follow the instructions in the instruction manual for the stand and use it correctly.
-  **Clean this product with a soft cloth.**
Do not use chemicals or solvents such as alcohol, thinner or benzene. It may damage this product.
-  **The tone bar of the product can not be removed.**
Do not try to remove the tone bar or carry this product by holding the tone bar. It may cause damage to the product or an unexpected accident.

About the change of pitch

Not limited to this product, the pitch of xylophones and metallophones generally alters due to the changes in temperature and humidity. The higher the temperature or humidity, the lower the pitch, and the lower the temperature or humidity, the higher the pitch. This is a phenomenon that occurs due to the characteristics of the instrument and is not a malfunction.

About the lid

Remove the lid of the case when playing. Close the lid and store after playing. The lid has a structure that can be easily removed, so make sure that the lid is firmly fitted into the fitting portion when storing.

SG-3200 Specifications

Note range	f ² ~c ⁵ (F57~C88) Chromatic 32 Notes
Materials	Tonebars / Steel Box / Beech
Dimensions	W73×D36×H5.5cm
Weight	9.5kg
Accessory	Case, Mallets x 2

Suggested stand "DKP-200" Specifications

Dimensions	Height 49.5 / 59 / 67 / 75 / 79.5 cm
	Maximum width 73 cm Depth 50.5 cm
Weight	2.5kg