


コントロール

◆ CONTROL (P. 81)

DISP KNOB MODE
MOMENTARY



ノブモード KNOB MODE

A new parameter, "Knob Mode" has added which allows you to adjust how a value is affected when a knob is moved.

MOMENTARY When a knob is moved, the value will change immediately.

ACROSS..... When a knob is moved the value will not change until the current value is arrived at by the movement of the knob, at which point the value will change.

NOTE: The Knob Mode affects for following knobs; [OVERDRIVE DEPTH], [EFFECT AMOUNT], [REVERB DEPTH].

新しいパラメーター「ノブモード」が追加されました。これは、つまみを動かした際に値に作用する時期を設定します。

MOMENTARY ... つまみを動かした瞬間に値に作用します。

ACROSS..... つまみを動かし、内部の値を超えた位置から値に作用します。

NOTE: ノブモードは以下のつまみに対して働きます。[OVERDRIVE DEPTH]、[EFFECT AMOUNT]、[REVERB DEPTH]

Please download separately for complete and latest owner's manual from our web site.

US: www.hammondorganco.com

EU: www.hammond.eu

最新版の完全な取扱説明書は、当社ウェブサイトより別途ダウンロードをお願いします。

JP: www.suzuki-music.co.jp

SUZUKI MUSICAL INST. MFG. CO., LTD

株式会社 鈴木楽器製作所

00457-40212
V1.51-210226