

## スズキハーモニカ8本ケース取扱説明書【10ホールズ・21穴複音ハーモニカ】

[ 10HC-8 (10ホールズハーモニカ用) / SHC-8 (21穴複音ハーモニカ用) ]

この度は、弊社製品をお買い上げいただきまして誠にありがとうございます。本製品を安全に、末永くご使用いただくため、この取扱説明書をよくお読みください。お読みになった取扱説明書は、なくさないよう大切に保管してください。


### 【ご注意】

- 演奏後のハーモニカは十分に水分をぬき、やわらかい布などできれいにふいてから収納してください。
- 本製品はハーモニカの収納を目的としており、衝撃から守るものではありません。ケースをぶつけたり、落としたりしないようご注意ください。破損の原因となるだけでなく、思わぬ怪我の原因になります。
- 自動車の中や暖房器具のすぐ近くなど、極端に熱くなる場所や湿度の高い場所での保管・使用は避けてください。破損の原因となります。
- 不安定な場所に置いたり、引っ掛けたりしないでください。破損の原因となるだけでなく、思わぬ怪我の原因になります。

### 【各部の名称】

- ① フック
- ② 肩掛けベルト
- ③ 金具(Dカ)
- ④ フードカバー
- ⑤ ポケット
- ⑥ 収納スペース

※ポケットには小型なドライバーなどを収納できます。



### 【仕様】

#### 10HC-8 (10ホールズハーモニカ用)

サイズ：ケース 150×45×142mm  
 340×30×142mm (展開時)  
 ベルト 650～1170×25mm (フック含む)  
 重量：206g

#### SHC-8 (21穴複音ハーモニカ用)

サイズ：ケース 160×45×205mm  
 350×30×205mm (展開時)  
 ベルト 650～1170×25mm (フック含む)  
 重量：262g

【使用例】フックの取り付け方を変えることでいろいろな使い方ができます。

- 肩に掛けて携帯
- 演奏時に(4本以下収納)
- 演奏時に(5本以上収納)



写真のようにフックを取り付けることで、肩に掛けて携帯することができます。



4本以下のハーモニカを収納して使用する場合は写真のようにケースを折り畳むことでコンパクトに使用できます。また、フードカバーを後ろへ折り込んでおくとスムーズに差し替えが行えます。



5本以上のハーモニカを収納して使用する場合は4本以下の場合と同様にフードカバーを後ろへ折り込んでおくとスムーズに差し替えが行えます。

**INSTRUCTIONS FOR SUZUKI HARMONICA 8-PCE CASE**
**[ 10HC-8(FOR 10-HOLE HARMONICA) / SHC-8(FOR 21-DOUBLE-HOLE HARMONICA) ]**


We thank you very much for purchasing our product. Please read this instruction manual carefully for lasting and safe use.

**[ NOTE ]**

- After performance, please remove moisture from the harmonica and dry it with a soft cloth, then replace it in this case.
- This product is not tough enough to protect the harmonica from the shock but to keep the harmonica. Please be careful not to hit the case on something hard or drop it. It may cause not only the damage but also an unintended injury.
- Please keep the case away from the car, the heater, an extremely hot or humid place to avoid any damage.
- Please avoid putting the case in an unstable place or hooking it to prevent from the any damage or an unintended injury.

**[ Name of parts ]**

- ① Hook
- ② Shoulder belt
- ③ Hardware (D kan)
- ④ Hood
- ⑤ Pocket
- ※ It can be used for storing a driver etc.
- ⑥ Storage space


**[ Specification ]**
**10HC-8 (for 10 holes harmonicas)**

Size : Case 150×45×142mm  
 340×30×142mm(when opened)  
 Belt 650~1170×25mm(including hook)  
 Weight: 206 g

**SHC-8 (for 21 holes tremolo harmonicas)**

Size : Case 160×45×205mm  
 350×30×205mm(when opened)  
 Belt 650~1170×25mm(including hook)  
 Weight: 262 g

**[ A VARIETY OF USES ]** There is a variety of uses by changing the attachment of the hook.

- CARRY SLINGING OVER THE SHOULDER
- STORAGE OF FOUR PCS OR LESS DURING PERFORMANCE
- STORAGE OF MORE THAN 5 PCS DURING PERFORMANCE



Attaching the hook as shown in the picture, you can carry the case slinging over the shoulder.



The case can be folded to allow for a compact storage of 4 pcs of harmonicas or less. With the hood cover inserted in the back, you can switch the harmonicas smoothly.



When 5 pcs of harmonicas and more are stored, please tuck the hood cover down in the back similarly, and you can switch the harmonicas smoothly.