

HAMMOND

オルガン用キャスターケース SCC-XKS/SCC-XKD 取扱説明書

この度は弊社製品をお買い上げいただき誠にありがとうございます。製品を安全に末永くご使用いただくため、この取扱説明書をよくお読みください。お読みになった取扱説明書はなくさないよう大切に保管してください。

対応モデル

※対応モデルの最新情報はホームページの製品情報ページをご確認ください。


ケース型番	仕様	用途/対応モデル
SCC-XKS	外寸/幅1,240×奥行465×高さ150mm 重量/4.9kg 主な材質/ポリエステル(生地)、発泡ポリエチレン(クッション材)、PVC(車輪)	シングルキーボード用 XK-7、XK-5
SCC-XKD	外寸/幅1,240×奥行630×高さ210mm 重量/6.2kg 主な材質/ポリエステル(生地)、発泡ポリエチレン(クッション材)、PVC(車輪)	デュアルキーボード用 XK-7D、XK-5+XLK-5、XLK-5

収納の向きと運搬時の注意事項




- オルガンにCU-1(レスリースイッチ)を装着したまま収納できますが、必ず下図の向きで収納してください。向きを誤ると、CU-1が破損する恐れがあります。また、収納後は最後までしっかりとファスナーを閉めてください。
- キャスターを使って運搬する際にケースを寝かせすぎるとキャスター付近の持ち手やケースのエッジ部分が地面に擦れて破損するおそれがあります。運搬の際は、これらの箇所が地面に擦れないようにご注意ください。

SCC-XKS



SCC-XKD



使用上の注意



警告 注意を無視した取り扱いをすると、死亡または重傷を負うおそれがあります。



禁止

- 対応モデル以外の製品、また目的以外に使用しないでください。
- 部品が破損している状態で使用しないでください。
- 火気や暖房器具を近づけないでください。
- 改造・分解はしないでください。
- 本製品にはキャスターが付いています。運搬の際は、周囲の人や物に衝突したり床を傷付けたりしないよう注意をしてください。
- 楽器を入れてケースを立てたまま放置しないでください。転倒し楽器が破損するおそれがあります。



注意 注意を無視した取り扱いをすると、障害や物的損害が発生するおそれがあります。



禁止

- 水分・湿気の多い場所や、ホコリの多い場所、直射日光の当たる場所での使用・保管はしないでください。
- お手入れにはアルコール、シンナー、ベンジン等の溶剤や、家庭用洗剤等は使用しないでください。
- 洗濯はできません。



行う

- お手入れは柔らかい布でから拭きしてください。
- 汚れがひどい場合は、かたく絞った布で水拭きするか、アルコール成分を含まない除菌クリーナーで拭いたあと、から拭きしてください。
- 濡れた時はかわいた布で水分を拭き取り、影干してよく乾かしてください。
- 本製品を廃棄するときは、地方自治体の条例または規則に従って処理してください。詳しくは、各地方自治体に問い合わせください。



お問合せ
フォーム

HAMMOND

Instruction manual of wheelie soft case for Hammond organ SCC-XKS/SCC-XKD

Thank you very much for purchasing our product. To ensure safe and long-lasting use of this product, please read this instruction manual carefully. After reading, please keep this manual in a safe place for future reference.

Compatible models * For the latest information on compatible models, please check the product information page on our website.


Case Model Name	Specifications	Usage/Compatible models
SCC-XKS	Outer Dimension / Width 1,240mm x Depth 465mm x Height 150mm Weight / 4.9kg Outer Dimension / Width 48.8 in. x Depth 18.3 in. x Height 5.9 in. Weight / 10.8 lbs Main materials / Polyester (fabric), Foamed polyethylene (cushion material), PVC (Wheels)	For single manual keyboards XK-7, XK-5
SCC-XKD	Outer Dimension / Width 1,240mm x Depth 630mm x Height 210mm Weight / 6.2kg Outer Dimension / Width 48.8 in. x Depth 24.8 in. x Height 8.2 in. Weight / 13 lbs. Main materials / Polyester (fabric), Foamed polyethylene (cushion material), PVC (Wheels)	For dual manual keyboards XK-7D, XK-5+XLK-5, XLK-5

Storage directions and safety precautions




- * You can store your keyboards with the (optional) CU-1 Leslie switch attached, but please store them in the direction shown in the picture below. It may cause serious damage to the CU-1 if the keyboard is stored in the wrong direction. Also, please fully close the zipper after storing the keyboard.
- * When transporting the case using the casters, do not tilt it excessively. Excessive tilting may cause the handle near the casters or the case edges to scrape against the ground, resulting in damage. Always ensure that these parts do not come into contact with the ground during transport.

SCC-XKS



SCC-XKD



Safety Precautions



Cautions/Warnings: Failure to follow these instructions and warnings may result in death, serious injury, and property damage.



Prohibited
Actions:

- *Do not use this product with models other than those specified, or for purposes other than its intended use.
- *Do not use the product if any parts are damaged.
- *Keep away from fire and heating appliances.
- *Do not attempt to modify or disassemble the product.
- *This product is equipped with casters. Be careful of the floor and surroundings when transporting it.
- *Do not leave the case standing upright with the instrument inside, as it may topple, causing damage to the instrument and nearby objects or people/pets.
- *Do not use or store the product in areas with high humidity, excessive moisture, dust, or direct sunlight.
- *Do not use solvents such as alcohol, thinner, or benzene, or household detergents for cleaning.
- *This product is not washable.



Maintenance

- *For cleaning, wipe with a soft dry cloth.
- *If the product is heavily soiled, wipe with a tightly wrung cloth dampened with water, or use a disinfectant cleaner that does not contain alcohol, then wipe dry with a clean cloth.
- *If the product gets wet, wipe off any moisture with a dry cloth and allow it to air dry in the shade.
- *When disposing of this product, follow the regulations or guidelines set by your local municipality. For details, please contact your local authorities.

SERVICE :

In the United States Contact:
HAMMOND SUZUKI USA, INC.
219 W. Wrightwood Ave., Elmhurst, IL 60126
UNITED STATES
Tel: (630) 543-0277 Fax: (630) 543-0279
Web site: www.hammondorganco.com
E-mail: info@hammondorganco.com

In European countries contact:
HAMMOND SUZUKI EUROPE B. V.
Parmentierstraat 8 4143 HA Leerdam
THE NETHERLANDS
Tel: (+31) 347-370 594
Web site: www.hammond.eu
E-mail: info@hammond.eu

For other countries:
SUZUKI CORPORATION
2-25-7, Ryoke, Chuo-ku, Hamamatsu,
Shizuoka Pref. 430-0852 JAPAN
Tel: (+81) 53-460-3781 Fax: (+81) 53-460-3783
Web site: suzukimusic-global.com
E-mail: suzukicorp@suzuki-music.co.jp