

# HAMMOND

## 組立式木製スタンド ST-XKD-W

### 取扱説明書

この度は弊社製品をお買いあげいただきまして誠にありがとうございます。製品を安全に末永くご使用いただくため、この取扱説明書をよくお読みください。お読みになった取扱説明書はなくさないよう大切に保管してください。

#### 使用上の注意

…禁止事項

…注意喚起事項

改造・分解はしないでください。

水分・湿気の多い場所や、ホコリの多い場所、極端に熱くなる場所、振動の多い場所、不安定な場所での使用・保管はしないでください。

お手入れは柔らかい布でから拭きしてください。シンナーやベンジン等は製品を傷めますので使用しないでください。



本製品をぶつけたり、落としたり、衝撃を与えないでください。

床を傷付ける恐れがありますので、製品を引きずらないでください。製品を移動する際は持ち上げるようにしてください。

平らで丈夫な床で組立・設置してください。床が傾いていたり、段差があると製品が不安定になり危険です。

組み立てた製品を移動する際は両側板を持って運んでください。

#### 部品一覧および製品仕様



中板×2枚  
(2枚とも同じです)

面ファスナー

ワイヤークランプ

寸法 : 1184 (W) × 566 (D) × 766 (H) mm (組立時)

重量 : 17kg

材質 : ブナ、合金

付属品 : ワイヤークランプ、面ファスナー

備考 : 天然木を使用しているため部品毎に色や木目が異なります。



#### 組み立て手順

組み立て時は不安定になります。必ず2人以上で作業してください。組み立ては平らな広い場所で、布やカーペットを敷いた上で行い、製品や周囲のものに傷がつかないようご注意ください。

#### 1. 背面側の中板を取付ける

①「固定金具」には向きがあります。  
上下の向きを確認してください。

②「中板」の「固定金具オス」を「側板L」の「固定金具メス」に矢印の方向にスライドしてはめ込みます。  
同様に「側板R」にはめ込みます。





#### 2. 内側の中板を取付ける

①「固定金具」の向きを確認し、「中板」の「固定金具オス」を「側板L・R」両側板の「固定金具メス」に同時に、矢印方向にスライドしてはめ込みます。  
1では「側板L」のあとに「側板R」にはめ込みましたが、ここでは「側板L・R」の両側板に同時にめ込むようにしてください。別々に行うとうまくはまりません。

②組立完成です。

XLK-5、XK-7Dを乗せる際は、XLK-5、XK-7Dの底部に開いている穴とゴム脚を合わせてください。

ご使用前にスタンドのゴム脚が楽器の底部穴にしっかりとはまっていることを確認してください。



エクスプレッション・ペダルやペダル鍵盤、レスリースピーカーなどをご使用される場合は、必要に応じて付属の面ファスナー、ワイヤークランプを使用してケーブルを脚などに固定します。

製造元 株式会社 鈴木楽器製作所

〒430-0852 静岡県浜松市中央区領家2-25-7 TEL(053)461-2325

販売元 鈴木楽器販売株式会社

事務所移転等のため、住所・電話番号が変わることがあります。

最新の情報に关しましては、  
弊社ホームページでご覧いただけます。

[www.suzuki-music.co.jp](http://www.suzuki-music.co.jp)

QRコード お問い合わせ  
フォーム 5212-MM-311-A  
00457-40233 v 1.0

# HAMMOND

## Instruction Manual for Wooden Stand ST-XKD-W

Thank you very much for purchasing our product. To ensure safe and long-lasting use, please read this instruction manual carefully before using the product. After reading, please keep this manual in a safe place for future reference.




### Safety Precautions

···Prohibited Actions

···Cautions

- !** Do not modify or disassemble the product.
- !** Do not use or store the product in areas with high moisture or humidity, excessive dust, extreme heat, on highly vibrating surfaces, or on unstable surfaces.
- !** For cleaning, wipe the product with soft, dry cloth. Do not use thinner, benzine, or other solvents, as they may damage the product.
- !** Do not crash, drop, or apply strong impact to the product.
- !** To avoid damaging the floor, do not drag the product. When moving the product, lift it instead of sliding it.
- !** Assemble and place the product on a flat and sturdy floor. Using it on a slanted or uneven surface may cause instability and result in injury.
- !** When moving the assembled product, hold both side panels to carry it.

### Parts List and Product Specifications


			
Side Panel L	Side Panel R	Middle Panel×2 (Both panels are identical.)	Wire Clamp
Dimensions	1184(W) × 566(D) × 766(H) mm (46 5/8"(W) × 22 9/32"(D) × 30 5/32"(H)) (when assembled)		
Weight	17kg (37 1/2lb)		
Materials	Beech, Alloy		
Accessories	Wire Clamp, Hook-and-loop Fastener		
Note	As natural wood is used, the color and wood grain may vary between parts.		

### Assembly Instructions

- !** During assembly, the product may become unstable. Be sure to have at least two people perform the assembly. Assemble the product in a spacious, flat area, and place a cloth or carpet underneath to prevent any damage to the product or surroundings.

#### 1. Attach the Middle Panel on the back side


- ① The brackets have a specific orientation. Please check the top and bottom before assembling.
- ② Slide the male bracket of the Middle Panel into the female bracket of the Side Panel L in the direction indicated by the arrow. Repeat the same for Side Panel R.



#### 2. Attach the inner Middle Panel

- ① Check the orientation of the brackets, then slide the male brackets of the Middle Panel simultaneously into the female brackets of both Side Panel L and Side Panel R in the direction of the arrows.


In Step 1, you first attached it to Side Panel L and then to Side Panel R, but here, make sure to insert it into both side panels at the same time. Doing it separately may prevent a proper fit.



- ② Assembly complete. When placing XLK-5 or XK-7D on the stand, align the holes on the bottom of the instrument with the rubber feet on the stand.

Before use, make sure that the rubber feet of the stand are securely fitted into the holes on the bottom of the instrument.

※1 Hook-and-loop Fastener



When using an expression pedal, pedal keyboard, or Leslie speaker, use the included hook-and-loop fasteners and wire clamps as needed to secure cables to the legs or other parts of the stand.

#### SERVICE :

In the United States

**HAMMOND SUZUKI USA, INC.**  
219 W. Wrightwood Ave., Elmhurst, IL 60126  
UNITED STATES  
Tel: (630) 543-0277 Fax: (630) 543-0279  
Website: [www.hammondorganco.com](http://www.hammondorganco.com)  
E-mail: [info@hammondorganco.com](mailto:info@hammondorganco.com)

In European countries

**HAMMOND SUZUKI EUROPE B. V.**  
Parmentierstraat 8 4143 HA Leerdam  
THE NETHERLANDS  
Tel: (+31) 347-370 594  
Website: [www.hammond.eu](http://www.hammond.eu)  
E-mail: [info@hammond.eu](mailto:info@hammond.eu)

For other countries

**SUZUKI CORPORATION**  
2-25-7, Ryoke, Chuo-ku, Hamamatsu,  
Shizuoka Pref. 430-0852 JAPAN  
Tel: (+81) 53-460-3781 Fax: (+81) 53-460-3783  
Website: [suzukimusic-global.com](http://suzukimusic-global.com)  
E-mail: [suzukicorp@suzuki-music.co.jp](mailto:suzukicorp@suzuki-music.co.jp)