

IC-200 Instrument Cart Assembly Sheet

Please read these instructions completely before you assemble. Make sure you have the parts and open end wrench.

Assembly List & Identification

| | | | |
|---|-------------------------------|---|-----------------------------------|
| A | Vertical Legs (2) | F | Large Knob Bolts (2) |
| B | Base Bolts & Washers (4 Each) | G | Adjustable Instrument Support (1) |
| C | Base Bolt Wrench (1) | H | Width Adjustment Knob Bolt (1) |
| D | Base Feet (2) | I | Instrument Supports (2) |
| E | Locking Casters (2) | J | Small Knob Bolts (2) |
| | | K | Instrument Locking Device (1) |

1 Remove the (4) bolts (B) that are threaded into the bottom of the vertical legs (A) and reinstall them through the holes provided in the base feet (D). Tighten the bolts with the wrench provided. Be sure both locking casters (E) are facing front.

2 Remove the larger knob bolts (F) from the adjustable instrument support (G) and reinstall them through the vertical legs at the height you have selected for your instrument. Tighten them by hand only.

3 Loosen the width adjustment knob bolt (H) and widen the instrument stand to fit your instrument. Hand tighten the knob bolt when the instrument base is centered and firmly aligned in supports (I).

4 Hand tighten the small knob bolts (J) on the right side of the locking device (K) to secure the instrument firmly into the stand.

